

Punch N'Cut Multi-Tool

INSTRUCTIONS



Poly Punch

Place rotating crescent against tubing. Apply forward pressure until punch pin pierces tubing. Release. Periodically clean punch pin to remove resin build up.



Emitter/Barb Insert

Insert emitter or barb in either rear or bottom barb holder. Place emitter barbed point against punched hole in tubing. Apply pressure until emitter barb pierces tubing. Remove tool by rotating sideways.



Emitter/Barb Insert with 1/4" Tubing

Install emitter with ¼" tubing attached into crescent slots on bottom of punch handle. Place shoulder of emitter on outside edge of handle with ¼" tubing pressed into crescents. While holding emitter assembly in crescents, place emitter barb against punched hole in tubing. Apply pressure until emitter pierces tubing. Remove tool and cut tubing as desired.



Emitter Removal

Place eased edge on bottom of punch handle against emitter at a 45° angle. Apply pressure until emitter edge is lifted and seated into crescents. While holding emitter assembly in crescents rotate tool backward until emitter is removed.



Tubing Cutter

Lightly squeeze handles together while rotating them up and down. As tubing is cut, reduce pressure at the end of the cut.

PRECAUTION:

Always wear eye protection.

Always wear safety gloves.

Cut only poly pipe, not metal objects.

Punch pin is sharp. Blade is sharp.

Keep away from children.

www.hydro-flowproducts.com



www.sunlightsupply.com

Product # 742185

